


Livorsi DTS Controls
Contour Base
Single Engine (2 handle)



When printing this template, be sure that page scaling options have been disabled.

For installation and operation instructions, please visit www.livorsi.com/tools.htm



Livorsi DTS Controls
Contour Base
Triple Shift/Throttle (3 handle)



When printing this template, be sure that page scaling options have been disabled.

For installation and operation instructions, please visit www.livorsi.com/tools.htm



Livorsi DTS Controls
Contour Base
Twin Engine (4 handle)



When printing this template, be sure that page scaling options have been disabled.

For installation and operation instructions, please visit www.livorsi.com/tools.htm

Overall Surface Area

7 3/4 in. (197 mm)

Cutout Area

5 1/8 in. (130 mm)

7 1/2 in. (190 mm)



715 Center Street Grayslake IL 60030
P: 847.752.2700 F: 847.752.2415
www.livorsi.com info@livorsi.com

**When printing this
template, make sure
the page scaling options
have been disabled.**

May not be to scale.

When printing this template, be sure that page scaling options have been disabled.
For installation and operation instructions, please visit www.livorsi.com/tools.htm

8 in. (203 mm)

Livorsi DTS Controls
Contour Base
Triple Engine (6 handle)

Overall Surface Area

Livorsi DTS Controls
Contour Base
Quad Engine (8 handle)

7 3/4 in. (197 mm)

Cutout Area

5 1/8 in. (130 mm)

9 13/16 in. (249 mm)



715 Center Street Grayslake IL 60030
P: 847.752.2700 F: 847.752.2415
www.livorsi.com info@livorsi.com

When printing this template, be sure that page scaling options have been disabled.
For installation and operation instructions, please visit www.livorsi.com/tools.htm

**When printing this
template, make sure
the page scaling options
have been disabled.**

May not be to scale.

10 5/16 in. (262 mm)