

Livorsi DTS Controls
Flat Base
Single Engine (2 handle)




When printing this template, be sure that page scaling options have been disabled.
For installation and operation instructions, please visit www.livorsi.com/tools.htm



Livorsi DTS Controls
Flat Base
Triple Shift/Throttle



When printing this template, be sure that page scaling options have been disabled.
For installation and operation instructions, please visit www.livorsi.com/tools.htm



Livorsi DTS Control
Flat Base
Twin Engine (four handle)

When printing this template, be sure that page scaling options have been disabled.
For installation and operation instructions, please visit www.livorsi.com/tools.htm

Overall Surface Area

Livorsi DTS Controls
Flat Base
Triple Engine (6 handle)

7 3/4 in. (197 mm)

Cutout Area

7 1/2 in. (90 mm)

5 1/8 in. (130 mm)

**When printing this
template, make sure
the page scaling options
have been disabled.**

May not be to scale.

8 in. (203 mm)



Overall Surface Area

Livorsi DTS Controls
Flat Base
Quad Engine (eight handles)

7 3/4 in. (197 mm)

Cutout Area

9 13/16 in. (249 mm)

**When printing this
template, make sure
the page scaling options
have been disabled.**

May not be to scale.



When printing this template, be sure that page scaling options have been disabled.
For installation and operation instructions, please visit www.livorsi.com/tools.htm

10 5/16 in. (262mm)